

# Installation Instruction

## NUMBER

MV-670

## PRODUCT RANGE

ANACONDA COMPACT FITTINGS  
FOR SEALTITE CONDUIT TYPE CNP

## INSTALLATION DESCRIPTION

FITTING TO CONDUIT



- Step 1. Mount the body (part D) into the enclosure (in a pre-cut female thread or in a knock-out in combination with a locknut).
- Step 2. Slide the back nut (part A), with the TPE clamping seal (part B) still inside, together over the conduit. Note: The TPE clamping seal (part B) must not be removed from the back nut (part A), but should be slid on the conduit whilst still inside the nut (otherwise you cannot get the TPE clamping seal back in the back nut afterwards).
- Step 3. Turn the ferrule (part C) firmly hand-tight in the conduit.
- Step 4. Place the ferrule into the already mounted body (part D). Slide the back nut and clamping ring towards the body and screw the back nut hand-tight.
- Step 5. Tighten the back nut with a wrench using the assembly torque of UL514B table 15, till the back nut closes tight on the body, and the fitting is installed liquid-tight.